

Beafon Watch 601



User Manual

Congratulations on your purchase of Bea-fon 601!

Please read these instructions to make the most of your smartwatch. We assume no liability for improper handling.

We are constantly striving to improve our products and services. Therefore, Beafon reserves the right to make changes and improvements to the products described in this documentation without prior notice.

The content of this user manual is provided as is. Beafon does not guarantee the accuracy or completeness of the content of this user manual.

There may be slight differences between the illustrations in the manual and your smartwatch; these are for reference only.

Please refer to your smartwatch directly.

If the text is too small and difficult to read, you can view a full version of the user manual on our website at www.beafon.com



.Product Specs

Size (Heart Rate Glass not included)	46.6 x 47.6 x 12.m
Weight (Strap not included)	34.8g
1.43" AMOLED Display resolution	466x466px
Protection class / Water resistance	IP68 / 5ATM (50m)
Battery power	300mAh
Bluetooth version	BLE 5.3
Bluetooth frequencies	2402 MHz - 2480 MHz
Bluetooth transmit power (EIRP) in watts BR / BLE	1.8mW / 1.5mW

Product Description

English


Please read this manual carefully before use, and keep it in a safe place for future reference.



How to Wear It?

In daily use, tie the watch comfortably to your wrist, about one finger width away from the wrist bone.

Adjust the wristband to ensure that the heart rate sensor can collect data normally.
Note: Wearing the watch too loosely may affect the data collection of the heart rate sensor.



How to Connect?

Due to our cooperation with AGM, the **AGM Nexus app** is required to operate the Beafon smartwatch. Download and install the "AGM Nexus" APP to better manage your watch, log in to your account, and enjoy more services.

Note: The APP version may have been updated, please follow the prompts according to the current APP version. Long press the function key to turn on the watch.

Scan the QR code displayed on the watch with your mobile phone, download and install the "AGM Nexus" APP You can also download and install the APP from the APP store, or scan the QR code below. Open the "AGM Nexus" APP and log in to your account. Select Add device and follow the instructions to add your watch.



AGM Nexus

APP QR code


Scan the QR code to download the APP
"AGM Nexus" APP

Note: When pairing, please make sure that the phone's Bluetooth is turned on and the watch is well connected to the phone.

If you cannot find the watch when adding the APP, or cannot connect to the phone during use, please press and hold the power button of the watch for 5 seconds to restore the factory settings, and then try again.

How to Use?

1. Open the control panel: swipe up from the bottom of the main screen.
2. View notifications: swipe down from the top of the home screen.
3. Switch widgets: swipe left or right on the home screen page.
4. Back: Swipe from the left edge to the right when you are on other screen pages.




Adjust & Install/Uninstall the Strap

Adjust the position of the buckle according to the circumference of the wrist. Align the slot of the strap with the watch, and then insert the strap into the watch until you hear a click. You can pull the strap to see if it is firmly installed.

To install or remove the strap, refer to the figure below.





Global Positioning System

GPS & A-GPS

The watch supports Global Positioning System (GPS) tracking. When you are doing outdoor sports such as running, GPs will automatically start to work and notify you when the positioning is successful, and exit tracking once you stop exercising. An open field outdoors is the best place for GPS tracking; and in crowded situations, raising your arm can better help GPs positioning. It is recommended to start exercising only when GPS starts to work.

The watch has an assisted GPS (A-GPS) function, which can accelerate GPS positioning through data directly from GPS satellites, Make sure that your watch is connected to your phone via Bluetooth, the data can be automatically synchronized to your watch from the "AGM Nexus" APP, and the A-GPS data will also be automatically updated.

If the data is not synchronized for 7 consecutive days, the A-GPS data will expire. if so, you need to re-acquire positioning information, You can update the positioning information on the outdoor sports page of the watch.


Declaration of Conformity

Beafon Mobile GmbH hereby declares that the product "Beafon Model 601" complies with the essential requirements and the relevant provisions of Directive 2014/53/EU (Radio Equipment Directive / RED), including the requirements under Article 3(3)(d), (e), and (f) regarding the protection of personal data and privacy, as well as safeguards against fraud and misuse.

The full Declaration of Conformity is available for viewing and download at the following link: <http://beafon.com/service/certification/>

Charging

When the battery is low, please charge the watch immediately.



Safety instructions

- When using the watch to measure your heart rate, keep your wrist still.
- In daily use, avoid wearing too tight. Keep the contact area dry and clean the strap with water regularly. If there are signs of redness and swelling in the skin contact area, immediately stop using the watch and seek medical help.
- Please use the included charging stand to charge the watch. Only use the power adapter that meets local safety standards or is certified and provided by a qualified manufacturer.
- When charging the watch, always keep the power adapter and charging stand dry. Do not touch them with wet hands. Do not expose the power adapter and charging dock to rain or other liquids.
- The working temperature of the watch is 0°C to 45°C. If the ambient temperature is too high or too low, the watch may malfunction.

- The watch has a built-in battery. To avoid damage to the battery or the watch, please do not disassemble or replace the battery by yourself. Only authorized service providers can replace the battery; otherwise, if the wrong type of battery is used, it will cause potential danger or even personal injury.
- Do not disassemble, puncture, hit, squeeze or throw the battery into fire. If the battery has any swelling or liquid leakage, stop using it immediately.
- Do not throw the watch or its battery into a fire to avoid explosion.
- This table is not a medical device, and any data or information provided in this table shall not be used as a basis for diagnosis, treatment and prevention of diseases.
- The watch and its accessories may contain small parts. To avoid suffocation or other hazards or damage caused by children, please keep the watch out of the reach of children. This watch is not a toy and can only be used by children under the supervision of adults.
- Abuse or improper handling of the battery can cause overheating, leakage or explosion.

To avoid possible injury, please do the following:

Do not squeeze or puncture the battery.

Do not short-circuit the battery or expose it to water or other liquids.

Keep the battery away from children.

Keep the battery away from fire.

Do not place the battery in an extremely high temperature environment or extremely low air pressure environment.

If the battery is damaged, or if you find any discharge or accumulation of foreign objects on the battery wires, stop using it. We recommend charging the battery every three months to prevent overcharging.

Do not put batteries in the garbage disposed of in the landfill. When disposing of the battery, please comply with local laws or regulations.

Further Information

If you have any questions or would like to learn more about one of our devices, feel free to contact us or visit our website:

www.beafon.com

Email: support@beafon.com

Customer Service

Please always send defective devices with all accessories such as charger, power supply, etc.

Also, remove any accessories attached for protection or aesthetic reasons before shipping. We accept no liability for loss.

Please only send a copy of the purchase receipt! Returns are not possible. For devices sent in for repair outside the warranty period, a cost estimate will be provided. This also applies to exclusion criteria such as moisture damage, lightning damage, unauthorized tampering, missing proof of purchase, etc.

Address

BEAFON MOBILE GmbH
4722 Peuerbach
Enzing 4
Austria

